


# MODEL : PUK50



## SPARE PARTS LIST

NO : MP-1101

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101048	3	24	Hexagon bolt	2B00-SM10*025	6
2	Allen bolt set	3B01-M10*055V	12	25	Breathing cover	2321008	1
3	Exhaust tube set	3B2-06*215	2	26	Oil seal	2N50-TC30*50*11	1
4	Air filter	2140009	3	27	Pulley	3PBF-145A230	1
5	Filter element	2142002	3	28	Plate washer	2B34-13*52*14	1
6	Cylinder head gasket	2G01-007	3	29	Hexagon bolt set	3B00-SM12*050V	1
7	Double head screw set	3B11-003-A	12	30	Exhaust elbow	2N06-06T06H	1
8	Cylinder	3201015G	3	31	Exhaust 3-way pipe	2N09-06H06T06H2	1
9	Cylinder gasket	2G04-009	3	32	Inlet&Exhaust washer	2B31-001	6
10	Piston ring set	3B32-80N	3	33	Inlet valve assembly	3B12-PU23	3
11	Piston set	3B31-80L	3	34	Unloading piston	2113009	3
12	Rod set	3B33-P2346	2	35	O-ring	2N52-P18V	3
13	Rod bush	2316001-B	3	36	Inlet valve holder	3110008	3
14	Crankcase	3301127	1	37	Hexagon bolt set	3B00-SM08*030V	12
15	Oil draining plug	2N33-002	1	38	Exhaust press plate	3126004	3
16	Oil sight gauge set	2303023B	1	39	O-ring	2N52-G45V	3
17	Oil filling plug set	2319003A	1	40	Exhaust valve assembly	3B11-NPP23	3
18	Bearing	2N35-6306	2	41	Unloading elbow	2N16-C01NW02M	1
19	Crankshaft & balancer	3304025	1	42	Unloading 3-way pipe	2N17-CW0201TW2M	2
20	Pulley key	2N47-63*09	1	43	Unloading tube set	3B2-02*450N	2
21	Rear bearing seat gasket	2G06-002	1	44	Rod set	3B33-P2337	1
22	Oil mesh	2352002	1	45	Exhaust 3-way pipe	2N09-06H06T06H4	1
23	Rear bearing seat	3311003	1				